

1.1 Installation of PMxxF (SSSP4):

1.1.1 How to do a “Factory Reset”

Note: If the TV has not been set up before, the TV will power on in the “Install menu”, shown below. The factory reset can then be skipped.



- Set source to PC
- TV has to be in standby
- On Samsung remote (TV Factory Menu): <MUTE><1><8><2><POWER>
- Option – Factory Reset – Factory Reset (Select each menu item by pressing Enter/OK button)



- TV will now power off
- Do a normal installation of the screen

1.1.2 Screen settings

- Power On TV
- Menu Language: Your language
- Display Orientation: Must stay as LANDSCAPE
- Auto Power Off: OFF
- Network Settings:
 - Wired.
 - Keep cable plugged in
 - Wireless.
 - Select SSID
 - Enter password
- Clock Set
 - Set Time and Date
- Play via: URL Launcher
- Enter URL: <https://ds.otrum.net/tizen>
- Select input: User Input
- Enter Device Name.
- Setup Completed - Start URL Launcher.

1.1.3 General Settings

Power Control:

Home – System – Power Control – Max Power Saving: OFF



Eco Solution:

Home – System – Eco Solution – Eco Sensor: OFF

